2020 HONDA CRF250RX

Maintenance schedule · tick each job as it's done

TIMELINE · HOURS ON THE METER

		DATE	HOURS
3.5 h	☐ Inspect engine oil & spark plug ☐ Clean air filter		
7 h	☐ Inspect engine oil & spark plug ☐ Clean air filter		
10.5 h	☐ Inspect engine oil & spark plug ☐ Clean air filter		
14 h	☐ Inspect engine oil & spark plug ☐ Clean air filter		
15 h	☐ Change engine oil ☐ Change oil filter		
17.5 h	☐ Inspect engine oil & spark plug ☐ Clean air filter		
21 h	☐ Inspect engine oil & spark plug ☐ Clean air filter		
24.5 h	☐ Inspect engine oil & spark plug ☐ Clean air filter		
28 h	☐ Inspect engine oil & spark plug ☐ Clean air filter		
30 h	☐ Change engine oil ☐ Change oil filter		

SCHEDULE

Inspect engine oil & spark plug
Every 3.5 hours or about 3.5 hours

Clean air filter
Every 3.5 hours or about 3.5 hours

Change engine oil
Every 15 hours or about 15 hours

Change oil filter
Every 15 hours or about 15 hours

EVERY RIDE & BY THE CALENDAR

- ☐ **Change engine oil** · After the first break-in ride
- ☐ **Replace oil filter** · After the first break-in ride

For reference only. Compiled from the manufacturer's owner's manual; it may contain errors and is not a substitute for it. Always follow your own manual and a qualified mechanic. FindMyDirtBike is not affiliated with Honda and accepts no liability for use of this sheet (findmydirtbike.com/terms).

2020 HONDA CRF250RX

Garage specs: fluids, plug, chain, tires and torques

FLUIDS

Oil type	10W-30
Engine oil	1.14 US qt (1.08 L)
Coolant	0.99 US qt (0.94 L)
Fuel capacity	2.25 gal

SPARK PLUG

Spark plug	NGK R0451B-9
Plug gap	0.024 – 0.028 in (0.60 – 0.70 mm)

CHAIN, SPROCKETS & TIRES

Chain size	520
Chain links	114
Front sprocket	13T
Rear sprocket	48T
Front tire	Dunlop AT81F 90/90-21 54M
Rear tire	Dunlop AT81 110/100-18 64M

TORQUE SPECS

Oil drain bolt	12 ft-lb (16 N·m, 1.6 kgf·m)
Oil filter cover bolts	7.4 ft-lb (10 N·m, 1.0 kgf·m)
Front axle nut	65 ft-lb (88 N·m, 9.0 kgf·m)
Front axle pinch bolts	15 ft-lb (20 N·m, 2.0 kgf·m)
Rear axle nut	94 ft-lb (128 N·m, 13.1 kgf·m)
Upper triple clamp bolts	16 ft-lb (22 N·m, 2.2 kgf·m)
Lower triple clamp bolts	15 ft-lb (20 N·m, 2.0 kgf·m)
Steering stem nut	80 ft-lb (108 N·m, 11.0 kgf·m)
Handlebar clamp bolts	16 ft-lb (22 N·m, 2.2 kgf·m)
Front brake caliper mounting bolts	22 ft-lb (30 N·m, 3.1 kgf·m)
Front brake disc nuts	12 ft-lb (16 N·m, 1.6 kgf·m)
Rear brake disc nuts	12 ft-lb (16 N·m, 1.6 kgf·m)
Rear sprocket nuts	24 ft-lb (32 N·m, 3.3 kgf·m)
Front sprocket bolt	23 ft-lb (31 N·m, 3.2 kgf·m)
Chain adjuster locknut	20 ft-lb (27 N·m, 2.8 kgf·m)
Shock absorber mounting nuts	32 ft-lb (44 N·m, 4.5 kgf·m)
Coolant drain bolt	7.4 ft-lb (10 N·m, 1.0 kgf·m)

For reference only. Compiled from the manufacturer's owner's manual; it may contain errors and is not a substitute for it. Always follow your own manual and a qualified mechanic. FindMyDirtBike is not affiliated with Honda and accepts no liability for use of this sheet (findmydirtbike.com/terms).