1993 HONDA XR100R

Maintenance schedule · tick each job as it's done

TIMELINE · MILES ON THE METER

		DATE	MILES
200 mi	☐ Change engine oil *(first)*		
1,000 mi	☐ Change engine oil ☐ Clean air filter ☐ Inspect spark plug		
2,000 mi	☐ Change engine oil ☐ Clean air filter ☐ Inspect spark plug		
3,000 mi	☐ Change engine oil ☐ Clean air filter ☐ Inspect spark plug		
4,000 mi	☐ Change engine oil ☐ Clean air filter ☐ Inspect spark plug		
5,000 mi	☐ Change engine oil ☐ Clean air filter ☐ Inspect spark plug		
6,000 mi	☐ Change engine oil ☐ Clean air filter ☐ Inspect spark plug		

SCHEDULE

Change engine oil
First at 200 mi, then every 1,000 mi

Clean air filter
Every 1,000 mi

Inspect spark plug
Every 1,000 mi

For reference only. Compiled from the manufacturer's owner's manual; it may contain errors and is not a substitute for it. Always follow your own manual and a qualified mechanic. FindMyDirtBike is not affiliated with Honda and accepts no liability for use of this sheet (findmydirtbike.com/terms).

1993 HONDA XR100R

Garage specs: fluids, plug, chain, tires and torques

FLUIDS

Oil type	10W-40
Engine oil	0.95 US qt (0.9 L)
Fuel capacity	1.72 gal

SPARK PLUG

Spark plug	NGK CR7HSA
Plug gap	0.024 - 0.028 in (0.6 - 0.7 mm)
Spark plug (cold climate)	NGK CR6HSA
Spark plug (extended high speed riding)	NGK CR8HSA

CHAIN, SPROCKETS & TIRES

Chain size	428
Front sprocket	14T
Rear sprocket	50T
Front tire	2.50-19 4PR
Rear tire	3.00-16 4PR

TORQUE SPECS

Oil drain bolt	18 ft-lb (25 N·m, 2.5 kgf·m)
Front axle	46 ft-lb (63 N·m, 6.3 kgf·m)
Rear axle nut	46 ft-lb (63 N·m, 6.3 kgf·m)

For reference only. Compiled from the manufacturer's owner's manual; it may contain errors and is not a substitute for it. Always follow your own manual and a qualified mechanic. FindMyDirtBike is not affiliated with Honda and accepts no liability for use of this sheet (findmydirtbike.com/terms).