# 2022 HONDA CRF250RX

Maintenance schedule · tick each job as it's done

## TIMELINE · HOURS ON THE METER

| | | DATE | HOURS |
|---|---|---|---|
| **3.5 h** | ☐ Inspect engine oil & spark plug<br>☐ Clean air filter | | |
| **7 h** | ☐ Inspect engine oil & spark plug<br>☐ Clean air filter | | |
| **10.5 h** | ☐ Inspect engine oil & spark plug<br>☐ Clean air filter | | |
| **14 h** | ☐ Inspect engine oil & spark plug<br>☐ Clean air filter | | |
| **15 h** | ☐ Change engine oil<br>☐ Change oil filter | | |
| **17.5 h** | ☐ Inspect engine oil & spark plug<br>☐ Clean air filter | | |
| **21 h** | ☐ Inspect engine oil & spark plug<br>☐ Clean air filter | | |
| **24.5 h** | ☐ Inspect engine oil & spark plug<br>☐ Clean air filter | | |
| **28 h** | ☐ Inspect engine oil & spark plug<br>☐ Clean air filter | | |
| **30 h** | ☐ Change engine oil<br>☐ Change oil filter | | |

## SCHEDULE

**Inspect engine oil & spark plug**
Every 3.5 hours or about 3.5 hours

**Clean air filter**
Every 3.5 hours or about 3.5 hours

**Change engine oil**
Every 15 hours or about 15 hours

**Change oil filter**
Every 15 hours or about 15 hours

## EVERY RIDE & BY THE CALENDAR

- ☐ **Change engine oil** · After the first break-in ride
- ☐ **Replace oil filter** · After the first break-in ride

For reference only. Compiled from the manufacturer's owner's manual; it may contain errors and is not a substitute for it. Always follow your own manual and a qualified mechanic. FindMyDirtBike is not affiliated with Honda and accepts no liability for use of this sheet (findmydirtbike.com/terms).

# 2022 HONDA CRF250RX

Garage specs: fluids, plug, chain, tires and torques

## FLUIDS

| | |
|---|---|
| Oil type | 10W-30 |
| Engine oil | 1.11 US qt (1.05 L) |
| Coolant | 1.10 US qt (1.04 L) |
| Fuel capacity | 2.11 gal |

## SPARK PLUG

| | |
|---|---|
| Spark plug | NGK SILMAR9A9S |
| Plug gap | 0.03 – 0.04 in (0.8 – 0.9 mm) |

## CHAIN, SPROCKETS & TIRES

| | |
|---|---|
| Chain size | 520 |
| Chain links | 114 |
| Front sprocket | 13T |
| Rear sprocket | 50T |
| Front tire | Dunlop AT81F 90/90-21 54M |
| Rear tire | Dunlop AT81 110/100-18 64M |

## TORQUE SPECS

| | |
|---|---|
| Oil drain bolt | 17 ft-lb (23 N·m, 2.3 kgf·m) |
| Spark plug | 16 ft-lb (22 N·m, 2.2 kgf·m) |
| Front axle nut | 65 ft-lb (88 N·m, 9.0 kgf·m) |
| Front axle pinch bolts | 15 ft-lb (20 N·m, 2.0 kgf·m) |
| Rear axle nut | 94 ft-lb (128 N·m, 13.1 kgf·m) |
| Upper triple clamp bolts | 16 ft-lb (22 N·m, 2.2 kgf·m) |
| Lower triple clamp bolts | 15 ft-lb (20 N·m, 2.0 kgf·m) |
| Handlebar clamp bolts | 16 ft-lb (22 N·m, 2.2 kgf·m) |
| Front brake caliper mounting bolts | 22 ft-lb (30 N·m, 3.1 kgf·m) |
| Rear sprocket nuts | 30 ft-lb (40 N·m, 4.0 kgf·m) |
| Front sprocket bolt | 23 ft-lb (31 N·m, 3.2 kgf·m) |
| Chain adjuster locknut | 20 ft-lb (27 N·m, 2.8 kgf·m) |
| Shock absorber mounting nuts | 32 ft-lb (44 N·m, 4.5 kgf·m) |

For reference only. Compiled from the manufacturer's owner's manual; it may contain errors and is not a substitute for it. Always follow your own manual and a qualified mechanic. FindMyDirtBike is not affiliated with Honda and accepts no liability for use of this sheet (findmydirtbike.com/terms).