# 1987 HONDA XR80R

Maintenance schedule · tick each job as it's done

## TIMELINE · MILES ON THE METER

| | | DATE | MILES |
|---|---|---|---|
| **600 mi** | ☐ Change engine oil<br>☐ Clean air filter<br>☐ Inspect spark plug | | |
| **1,200 mi** | ☐ Change engine oil<br>☐ Clean air filter<br>☐ Inspect spark plug | | |
| **1,800 mi** | ☐ Change engine oil<br>☐ Clean air filter<br>☐ Inspect spark plug | | |
| **2,400 mi** | ☐ Change engine oil<br>☐ Clean air filter<br>☐ Inspect spark plug | | |
| **3,000 mi** | ☐ Change engine oil<br>☐ Clean air filter<br>☐ Inspect spark plug | | |
| **3,600 mi** | ☐ Change engine oil<br>☐ Clean air filter<br>☐ Inspect spark plug | | |

## SCHEDULE

**Change engine oil**
Every 600 mi or 6 months

**Clean air filter**
Every 600 mi or 6 months

**Inspect spark plug**
Every 600 mi or 6 months

For reference only. Compiled from the manufacturer's owner's manual; it may contain errors and is not a substitute for it. Always follow your own manual and a qualified mechanic. FindMyDirtBike is not affiliated with Honda and accepts no liability for use of this sheet (findmydirtbike.com/terms).

# 1987 HONDA XR80R

Garage specs: fluids, plug, chain, tires and torques

## FLUIDS

| | |
|---|---|
| Oil type | 10W-30 |
| Engine oil | 0.85 US qt (0.8 L) |
| Fuel capacity | 1.7 gal |

## CHAIN, SPROCKETS & TIRES

| | |
|---|---|
| Chain size | 420 |
| Front sprocket | 14T |
| Rear sprocket | 46T |
| Front tire | 2.50-16 knobby 4-ply rating |
| Rear tire | 3.60-14 knobby 4-ply rating |

## TORQUE SPECS

| | |
|---|---|
| Oil drain bolt | 18 ft-lb (25 N·m, 2.5 kgf·m) |
| Spark plug | 10 ft-lb (14 N·m, 1.4 kgf·m) |
| Front axle nut | 46 ft-lb (62 N·m, 6.3 kgf·m) |
| Rear axle nut | 46 ft-lb (62 N·m, 6.3 kgf·m) |
| Upper triple clamp bolts | 8.1 ft-lb (11 N·m, 1.1 kgf·m) |
| Lower triple clamp bolts | 19 ft-lb (26 N·m, 2.7 kgf·m) |
| Steering stem nut | 55 ft-lb (74 N·m, 7.5 kgf·m) |
| Handlebar clamp bolts | 8.9 ft-lb (12 N·m, 1.2 kgf·m) |
| Rear sprocket nuts | 24 ft-lb (32 N·m, 3.3 kgf·m) |
| Shock absorber mounting bolts | 25 ft-lb (34 N·m, 3.5 kgf·m) |

For reference only. Compiled from the manufacturer's owner's manual; it may contain errors and is not a substitute for it. Always follow your own manual and a qualified mechanic. FindMyDirtBike is not affiliated with Honda and accepts no liability for use of this sheet (findmydirtbike.com/terms).